

Cerberus® CS1145 Fire detection system

Operating instructions

Software version EP5-Z3

Data and design subject to change
without notice. / Supply subject to
availability.

© Copyright by
Siemens Building Technologies AG

We reserve all rights in this document
and in the subject thereof. By
acceptance of the document the
recipient acknowledges these rights
and undertakes not to publish the
document nor the subject thereof in
full or in part, nor to make them
available to any third party without our
prior express written authorization,
nor to use it for any purpose other
than for which it was delivered to him.


CERBERUS CS1145 series Fire Indicator Panel. Model Number CI1145

Approved to AS4428.1

Siemens Building Technologies
Cerberus Division






CH-8708 Männedorf
Switzerland

411 Ferntree Gully Road
Mount Waverley 3149
Australia
Tel: 03 9550 9245

Introduction	4
Operating access	5
Control console layout	6
Message categories	8
Terminology 'Area', 'Section' and 'Zone'	9
Normal operation	10
Mains available	10
Operating states 'Manned' and 'Unmanned'	11
Quick reference instruction	12
Cerberus Alarm Concept	13
Alarm – general information	14
 Alarm – what to do ?	16
Detector zone isolation	18
Detector isolation	20
Fault	21
Detector test	22
Installation test	26
Renovation mode	27
Remote transmission isolation	28
Alarm devices isolation	29
Printer isolation	30
Printer paper replenishing	31
Lamp test	32
Alarm counter	33
Event memory	34
Set clock and date	35
Overview operating menus	36

Introduction

This Cerberus fire detection installation consists of the following components:

System components			Equipped
Operating console	 Type 'CI1145'		<input type="checkbox"/>
Series of fire detectors ?		Interactive detectors	<input type="checkbox"/>
		Addressable detectors	<input type="checkbox"/>
		Collective detectors	<input type="checkbox"/>
Includes also extinguishing SECTIONS ?		CO2	<input type="checkbox"/>
		N2	<input type="checkbox"/>
		water	<input type="checkbox"/>
		<input type="checkbox"/>
Printer connected ?	 Location	<input type="checkbox"/> yes <input type="checkbox"/> no
Remote transmission connected ?		<input type="checkbox"/> yes <input type="checkbox"/> no	
Cerberus Alarm Concept activated ? (operating 'manned' / 'unmanned' used ?)		<input type="checkbox"/> yes <input type="checkbox"/> no	
Multi area installation ?		<input type="checkbox"/> yes <input type="checkbox"/> no	
Duration of emergency power operation ?		 hours

This table to be filled in by the commissioning engineer.

Note

Make sure that all system operators of the fire detection installation are sufficiently instructed. If there is any doubt about any function or measures to be taken call the local service organization for assistance.

Operating access

General:

The control console is protected by a front door against unauthorized or unintentional manipulation. So no further password protection is necessary except for some special functions which are restricted to the service engineer.

Possible access levels:

- Access level 1 **Everybody** → access to all user functions
- Access level 3 **Service** → full privileges (service engineer only)


How to get USER operating access:

Just open the front door. Immediate access to all user functions is possible.

→ See 'Overview operating menus' on pages 36 up to 41

How to get SERVICE ENGINEER operating access:

Log in

1. Type in your service password via keypad (an entering box is displayed) and press 

→ The confirmation «password CORRECT» or «password INCORRECT» is displayed

→ To cancel keying errors press 

2. Press 

3. Start operation

```
MON 20-SEP-1999   11:23:44

password : _

0..9,del:password   ok:enter   c:end
```

```
password CORRECT
authorized access level: 2.1
```


```
MAIN MENU
FIRE section
EXTINGUISHING section
CONTROL in- /outputs
GEOGRAPHICAL location
DEVICE level
logical address (CSX no.)
ok:select   F1:function   C:end
```

Log out

Log out is not required because operating is automatically inhibited if no key is pressed within a certain time (programmable timeout 2... 10 minutes).

Control console layout

Firefighter facility



Special keys and indicators

List Handling

1	Information indicator & key	Information message list handling & indication	see page 8
2	Isolation indicator & key	Isolation message list handling & indication	see page 8
3	Alarm indicator & key	Alarm message list handling & indication	see page 8
4	Fault indicator & key	Fault message list handling & indication	see page 8

Operating states

5	Premises manned indicator & key	Premises manned / unmanned switch over & indication	see page 11
---	--	---	-------------

Alarm devices

6	Alarm device isolate(d) indicator & key	Isolation / de-isolation of alarm devices	see page 29
7	Alarm device active indicator & key	Activation / deactivation of Alarm devices	
8	Alarm device fault indicator	Indicates fault of alarm devices	

Remote Transmission

9	Alarm delay off indicator & key	Immediately initiates the alarm remote transmission	see page 16
10	Remote alarm isolate(d) indicator & key	Disables alarm remote transmission	see page 28
11	Remote alarm active indicator	Indicates active alarm remote transmission	
12	Remote transmission fault indicator	Indicates faults of the alarm remote transmission	

Control and System

13	Detector test mode indicator	Indicates zones are in mode 'detector test'	see page 22
14	Control function isolated indicator	Indicates isolated control functions	
15	Mains available indicator	Indicates main power supply normal operation	see page 10
16	System fault indicator	Indicates fatal system fault	

Firefighter facility

17 **Text display** with yellow illumination. *dark*, if no danger message («Alarm») is pending and no operator activity is in progress.

17a **Information bar**

Information is context dependent

17b **Message part**

e.g. abnormal states or menu items to be selected

17c **Instruction bar**

Indicates the currently possible actions

Common indicators

18 **ALARM** indicator

Indicates pending zone alarms (blinking if unacknowledged)

19 **FAULT** indicator

Indicates pending zone faults (blinking if unacknowledged)

20 **ISOL** indicator

Indicates pending zone isolations (blinking if unacknowledged)

Sound handling

21 **EXT BELL ISOL** indicator

Indicates external bells isolated

22 **WARN SYS ISOL** indicator

Indicates warning system isolated

23 **EXT BELL ISOLATE** key

To isolate/de-isolate the external bells

24 **WARN SYS ISOLATE** key

To isolate/de-isolate the warning system

Message scrolling

25 **PREV↑** key

To scroll messages upwards in the text display

26 **NEXT↓** key

To scroll messages downwards in the text display

Zone handling

27 **ACK** key

To acknowledge new messages (e.g. alarms, faults)

28 **RESET** key

To reset alarms

29 **ISOLATE** key

To isolate / de-isolate zones

Function key pad

Message scrolling

30 **↑** **Scroll up** key

Corresponds to key **25** **PREV↑** on Firefighter facility

31 **↓** **Scroll down** key

Corresponds to key **26** **NEXT↓** on Firefighter facility

Message & display control

32 **F1** key

Calls context menu (corresponding function list)

33 **F2** key

Calls main menu

34 **ok** key

Displays intervention text or expands messages

35 **ⓧ** **Delete** key

Deletes one character to the left of the cursor

36 **C** **Clear** key

Cancels current input

Numeric keys

37 **0..9** **Numeric keys**

To set clock and date e.g.

see page 12

see page 35

Message categories

There are the following message categories:

- **Alarms** → danger messages acquired by the system Priority 1
- **Faults** → messages that require an immediate response Priority 2
- **Isolation** → system components out of service Priority 3
- **Information** → messages that do not require an immediate response Priority 4

The screenshot shows a control panel for a 'FIREFIGHTER FACILITY'. On the left, there are buttons for 'ALARM', 'FAULT', and 'ISOL'. Below these are 'EXT BELL' and 'WARN SYS' buttons, each with an 'ISOLATE' sub-button. In the center, a display shows a 'Fire brigade REQUESTED' message with details: '01 AUTOM. ALARM SMOKE', 'main building / 1st floor', 'room 104', and 'Zones: 1'. Below the display are 'PREV', 'NEXT', and 'ACK' buttons. At the bottom, there are eight numbered selection keys (1-8) for different message categories: 1. Information, 2. Premises manned, 3. Alarm delay off, 4. Detector test mode, 5. Isolation, 6. Alarm device isolate(d), 7. Remote alarm isolate(d), 8. Control function isolated. To the right of the panel, a list of faults is displayed under the heading 'FAULTS' and 'Zones: 1'. The list shows '01 detector main building / 1st floor room 104' with a 'NACK' status. Below this, there are buttons for 'F1: function' and 'F2: menu'. Further down, the 'ISOLATION' section shows '01 detector main building / 1st floor room 104' with a 'NACK' status, and buttons for 'F1: function' and 'F2: menu'. At the bottom right, the 'Information' section shows 'Total: 1' and '01 detector main building / 1st floor room 104' with buttons for 'F1: function' and 'F2: menu'.

1 Information display field

Press key 2 to display the **information** list.

- Certain information messages are displayed spontaneously (e.g. warnings) if no message with a higher priority is pending.

3 Isolation display field

→ The indicator is blinking if there are unacknowledged messages in then list

Press key 4 to display the list of **disabled system components**.

- This message type is displayed spontaneously if no message with a higher priority is pending.

5 Alarms display field

→ The indicator is blinking if there are unacknowledged messages in then list

Press key 6 to display the list of **alarms**.

- This message type is always displayed spontaneously and overwrites all other message categories

7 Faults display field

→ The indicator is blinking if there are unacknowledged messages in then list

Press key 8 to display the list of existing **faults**.

- This message type is displayed spontaneously if no message with a higher priority is pending.


Note

Switching from one message category to another is always possible by pressing the corresponding selection key. If a lower priority is selected, the system always goes back after a short time-out, to that message category with the highest priority.

Terminology 'Area', 'Section' and 'Zone'

What is an «Area»?


It normally covers **a whole building** or part of a building and represents also the operating level.
This is the logical designation for **several, usually adjacent sections**



AREA		
01	main building	
02	factory	
ok:section	F2:menu	F1:function

What is a «Section»?

It normally covers **a floor** or part of a floor in a building.
This is the logical designation for **several, usually adjacent zones**




SECTION 'fire'		
01	ground floor	
02	first floor	
03	second floor	
ok:zone	F2:area	F1:function

What is a «Zone»?

It normally comprises **one room** of a building (with collective detectors => several rooms)
It is the logical designation of a **detector group containing at least one detector**
Automatic fire detectors, manual call points and control outputs are always assigned to different ZONES

For this reason we have

- zones comprising **automatic fire detectors**
- zones comprising **manual call points**
- zones comprising **control outputs**



ZONES 'fire'		
01	room 103	
02	room 104	
03	room 105	
ok:element	F2:section	F1:function


Normal operation / Mains available

What is «Normal operation»?

- The system is ready for receiving danger messages
- No alarm and no fault messages are pending and no part of the system is isolated

→ The system can either be in state «manned» or «unmanned» (see page 11)

→ The operating states «manned» / «unmanned» are information messages. This means that even in «normal operation» at least this message is always pending in the information list **1**



What is «Mains available»?

The green indicator **2** in the display field «Mains available» shows the state of the main power supply:

- It is ON as long as the main power supply is in normal operation.
- It is OFF if the the main power supply fails and the control unit runs on battery.

Operating states 'manned' and 'unmanned'

Is the Cerberus Alarm Concept activated? ☐ Yes
☐ No

Basic rules

The operating states «Manned» and «Unmanned» are only relevant for systems in which the signals for automatic fire detectors and manual call points are processed differently, that means, the *Cerberus Alarm Concept* is activated. The switchover can be performed manually or automatically.


Operating state «manned»

Means: The **operating person** responsible for «Alarm» investigation **is on site**.

Indicator **1** in the display field «Premises manned» is ON.

Operating state «unmanned»

Means: The responsible **operating person is not on site**.



Manual switch over from «manned» to «unmanned» or vice versa

Note

For several areas, this function works only, if **all** areas are in the same state (unmanned or manned).
 With this function you switch over **all** areas from manned to unmanned or vice versa.

1. Switch over by pressing key **2** (toggling key)
 → Confirmation prompt is displayed
2. Confirm the switchover by pressing the **ok** key **3**
 → The new operating state is shown in the display
 → In the «manned mode» the state indicator **1** is ON

INFORMATION	Total: 2
01 manned building A	
02 manned building B	
F1: function	F2: menu

actual state: manned

switch over ?

ok: switch over C: cancel

switched over !

actual state: unmanned

Note

The switchover from «manned» to «unmanned» (or vice versa) is also possible via the menu.
 If several organizationally autonomous systems are operated via a common multi-area terminal (areas with manned state, other areas with unmanned state) the state can only be changed via the menu, the «Premises manned» state indicator **1** is flashing.

Automatic switchover

From «unmanned» to «manned»: ☐ No ☐ Yes, time =
 From «manned» to «unmanned»: ☐ No ☐ Yes, time =

Quick reference instructions

How to start operating ?

1. Press **F2**
→ The **MAIN MENU** is displayed
2. Select desired function in 'MAIN MENU' by using the arrow keys **↑** and **↓**
3. Then press **OK**
→ option selected is shown inverse

MAIN MENU		
FIRE detection		
EXTINGUISHING sections		
CONTROL in- /outputs		
GEOGRAPHICAL location		
DEVICE level		
logical address (CSX no.)		
ok:select	F1:function	C:end

Function 'FIRE detection'

- to navigate to a fire detection SECTION or ZONE or ELEMENT (= detector) in order to
- isolate or reactivate detector zones
 - set detector zones on mode 'detector test' or to terminate 'detector test' , etc.

Function 'Extinguishing section'

- to navigate to an extinguishing SECTION in order to
- isolate detector zones related to the selected extinguishing section
 - set detectors related to the selected extinguishing section on mode 'detector test' or to terminate
 - test the extinguishing 'alarm horn' or 'warning panel' , etc.

Function 'CONTROL in-/ outputs'

- to select a control SECTION or ZONE in order to
- isolate or reactivate a fire control function (e.g. air-conditioning shut down, etc.)
 - initiate manually or deactivate a fire control function, etc.

Function 'GEOGRAPHICAL location'

- to select any SECTION or ZONE in order to
- isolate or reactivate a zone, etc.

Function 'DEVICE level'

- to initiate a specific function such as
- lamp test
 - printer test, also to isolate or de-isolate the printer, etc.

Function 'LOGICAL address (CSX. no.)'

- to jump directly to a known logical location
- the complete address (AREA no./ SECTION no./ ZONE no./ELEMENT no.) must be known


Notes

- Full list of all possible functions see 'Overview operating menus' on pages 36 to 41
- The text 'MAIN MENU' is sometimes abbreviated to 'MENU' because of the limited text length in the display

Cerberus Alarm Concept

How does the *Cerberus Alarm Concept* function?

When the system operates in «manned» mode, manual call points and automatic fire detectors trigger **different actions** in the event of an alarm.



Alarm acknowledgement time «V1»

- This is a countdown time that is active for automatic detectors when the system operates in «manned» mode.
- Checks whether someone acknowledges the danger alarm message **within the preprogrammed time**.
- On expiration of this time the alarm is transmitted to the fire department.
- The remaining time is displayed in minutes and seconds.

V1 = minutes


Alarm investigation time «V2»

- This is a countdown time that is active for automatic detectors when the system operates in «manned» mode.
- Limits the time for **investigating the fire location** to an individually programmed time.
- On expiration of this time the alarm is transmitted to the fire department.
- The remaining time is displayed in minutes and seconds.
- In case of minor incidents, an alarm must be reset before V2 expires.

V2 = minutes

Alarm – general information

How are alarm messages shown in the text display?



Text Display

The display consists of 3 parts:

- Information bar on the top line
Reports the status of remote transmission. One of the following texts is indicated:
 - Fire brigade REQUESTED
 - FIRE BRIGADE in ... min
 - CALL fire brigade: Tel. 000
- Message part
The display can show 2 messages simultaneously:
 - Upper section shows **1st message**
 - Lower section shows **last message**
- Instruction bar
Indicates the currently possible actions.

Message scrolling

If more than 2 messages have been reported, **scrolling** becomes necessary in order to show all reported messages in the 'upper section' (one after the other).

Scrolling is done by **PREV** and **NEXT** or with the arrow keys **↑** and **↓**.

Message text

The message consists of 3 lines:

- First line:
 - A message number (which does not necessarily correspond to the alarm order)
 - The kind of detection device: automatic detector (SMOKE, HEAT, FLAME) or manual call point (MCP). Isolated alarms have the additional text 'ISOL'
 - The Message state (see below)
- Second line:
 - Customer text line 1 with programmable additional location information (logical address of the alarming zone)
- Third line:
 - Customer text line 2

Message state

Most messages have to be acknowledged. If they occur, they are in the state 'not acknowledged'. By pressing **ACK** they change to the 'acknowledged' state. The state is indicated by the texts 'NACK' for 'not acknowledged' and 'ACKD' for 'acknowledged' at the end of the first line of the message.

Messages which do not have to be acknowledged do not have these texts.

Message order

Messages are presented in the following order:

1. unacknowledged alarms
2. acknowledged alarms
3. isolated alarms

Within these categories the messages are sorted chronologically.

Acknowledge

→ Each message has to be acknowledged separately

1. Select the desired unacknowledged message
2. Press **ACK**
 - The message state text changes from 'NACK' to 'ACKD'
 - The unacknowledged message is placed on top

Fire brigade REQUESTED		Zones: 2
01 AUTOM. ALARM SMOKE		NACK
main building / 1st floor room 104		01/001/004
02 AUTOM. ALARM HEAT		NACK
main building / 1st floor room 102		01/001/006
F1:function ok:interv.text F2:menu		

message state
NACK = not acknowledged

Supplementary information

The logical address of the alarming zone (if programmed)

Fire brigade REQUESTED		Zones: 2
01 AUTOM. ALARM HEAT		NACK
main building / 1st floor room 104		01/001/006
02 AUTOM. ALARM SMOKE		ACKD
main building / 1st floor room 102		01/001/004
F1:function ok:interv.text F2:menu		

logical address of the alarming zone

message state
ACKD = acknowledged

How can an intervention text be read out ?

1. Press «Alarms» key and select the desired message by pressing **NEXT↓** or **PREV↑**, if necessary (the selected message is displayed in inverted colors)
2. Press **OK**
 - The intervention text is displayed (if programmed)
3. Pressing **OK** again returns back to the original message

Fire brigade REQUESTED		Zones: 2
01 AUTOM. ALARM SMOKE		ACKD
main building / 1st floor room 104		01/001/004
02 AUTOM. ALARM HEAT		ACKD
main building / 1st floor room 102		01/001/006
F1:function ok:interv.text F2:menu		

Fire brigade REQUESTED		Zones: 2
DANGER: hazardeous materials !!		
-> alert emergency squad		
ok:message		

intervention text

Reset

→ Each message has to be reset separately

→ Unacknowledged messages are reset in the same way as acknowledged ones


1. Select the message to be reset
2. Press **RESET**
 - The confirmation dialog is displayed
3. Press **ACK** to confirm

Fire brigade REQUESTED		Zones: 2
01 AUTOM. ALARM SMOKE		ACKD
main building / 1st floor room 104		01/001/004
02 AUTOM. ALARM HEAT		ACKD
main building / 1st floor room 102		01/001/006
F1:function ok:interv.text F2:menu		

PRESS ACKNOWLEDGE TO CONFIRM RESET		
any other key:end		

Alarm – what to do ?

Top line of display reports status of remote transmission:



'CALL fire brigade: TEL. 000'

'FIRE BRIGADE in'

Fire brigade REQUESTED

► 'Fire brigade REQUESTED'

→ Alarm is already transmitted

1. Press **ACK** **1** for each pending alarm message
2. Read the fire location of the 1st alarm in the upper half of the text display field
3. Go to the fire location
4. Decide on «Emergency» or «Minor incident»:

Emergency:

Save people
Fight the fire

Minor incident:

Immediately try to stop the fire brigade
Press **RESET** **3**
and acknowledge by **ACK** **1**
for each pending alarm message
→ The system reverts to normal operation

► 'FIRE BRIGADE in 4:31 (min)'

→ Alarm will be transmitted in the time indicated

1. Press **ACK** **1** for each pending alarm message (before time is 0:00)
2. Read the fire location of the 1st alarm in the upper half of the text display field
3. Go to the fire location
4. Decide on «Emergency» or «Minor incident»:

Emergency:

Immediately actuate nearest manual call point or the key 'Alarm delay off' 2
→ The alarm message is transmitted

Minor incident:

Immediately press **RESET** **3**
and acknowledge by **ACK** **1**
for each pending alarm message
→ The system reverts to normal operation

► 'CALL fire brigade: TEL. 000'

1. Press **ACK** **1** for each pending alarm message
2. Read the fire location of the 1st alarm in the upper half of the text display field
3. Go to the fire location
4. Decide on «Emergency» or «Minor incident»:

Emergency:

Immediately call the fire brigade (e.g. TEL. 000)
→ the alarm message is transmitted

Minor incident:

Immediately press **RESET** **3**
and acknowledge by **ACK** **1**
for each pending alarm message
→ The system reverts to normal operation

What to do if alarm cannot be reset ?

As long as a detector still detects a fire phenomena (smoke, heat, flame) the alarm **cannot** be reset. In order to remove such an alarm the corresponding detector zone has to be isolated.

ZONE isolation procedure if zone is on alarm (Example ZONE 'fire')

1. Select ZONE on alarm to be isolated

ALARMS	Zones: 1
01 AUTOM. ALARM SMOKE main building/1st floor conference room	ACKD
F1:function	F2:menu

2. Press **ISOLATE**
→ The confirmation dialog is displayed

PRESS ACKNOWLEDGE TO CONFIRM ISOLATE	
any other key:end	

3. Press **ACK** to confirm
→ The selected ZONE is isolated
→ It is displayed spontaneously in the Alarms list
(if no messages of higher order are pending)
→ The isolated ZONE is as well displayed in the Isolation list

ALARMS	Zones: 1
01 ISOL AUTOM. ALARM SMOKE main building/1st floor conference room	ACKD
F1:function	F2:menu

ZONE de-isolation procedure

1. Select the isolated ZONE in the *alarms* list
→ The message is displayed in inverted colors
2. Press **ISOLATE**
→ The ZONE is reactivated, that is, the isolation is cancelled

ALARMS	Zones: 1
01 ISOL AUTOM. ALARM SMOKE main building/1st floor conference room	ACKD
F1:function	F2:menu

Note

The isolated ZONE may for de-isolation as well be selected in the *Isolation* list

ISOLATION	Zones: 1
01 detector zone ISOLATED main building/1st floor conference room	
F1:function	F2:menu

Detector zone, temporary isolation

What is ISOLATION of a ZONE ?

Isolated zones have the following characteristics:

- The zone state (alarm and fault) is evaluated and displayed
- Alarms on isolated zones do NOT activate any control outputs (e.g. warning system, external bell, extinguishing, remote transmission)
- Isolated alarms are identified by the text 'ISOL'

When does a ZONE have to be isolated ?

If zones are NOT in alarm

ZONES equipped with automatic fire detectors or manual call points can be temporarily isolated. This is only necessary in exceptional situations, for example while major construction is in progress:

- ZONE with smoke detectors → if smoke or dust is produced by unusual work
- ZONE with heat detectors → if heat or steam is produced by unusual work
- ZONE with manual call point → if there is a possibility of inadvertent actuation

As soon as conditions have returned to normal, ISOLATED ZONES must immediately be de-isolated again.

If zones are in alarm

If zones in alarm cannot be reset because they still detect an alarm condition (e.g. smoke) then they can be isolated.

As soon as conditions have returned to normal, ISOLATED ZONES must be immediately switched on again.

ZONE isolation procedure if zone is NOT on alarm (Example ZONE 'fire')

1. Press **F2**
→ The MAIN MENU is displayed
2. Press **ok**
→ The AREAS overview is displayed
Press **↓** to select the desired AREA
3. Press **ok**
→ The SECTIONS overview is displayed
Press **↓** to select the desired SECTION
4. Press **ok**
→ The ZONES overview is displayed
Press **↓** to select the desired ZONE

```
MAIN MENU
FIRE detection
EXTINGUISHING sections
CONTROL in- /outputs
GEOGRAPHICAL location
DEVICE level
logical address (CSX no.)
ok:select      F1:function      C:end
```

```
AREAS
01 main building
02 factory
ok:section      F2:menu      F1:function
```

```
SECTIONS 'fire'
01 ground floor
02 1st floor
ok:zone         F2:area      F1:function
```

```
ZONES 'fire'
01 room 101
02 room 102
03 storage room
04 conference room
05 corridor
ok:element      F2:section   F1:function
```

→ continued on next page

5. Press **F1**

→ The *FUNCTION LIST 'zone'* is displayed

Select the function 'ISOLATE zone'

Press **OK** to confirm

→ The selected *ZONE* is isolated

→ It is displayed spontaneously (if no messages of higher priority are pending).

FUNCTION LIST 'zone':		
ISOLATE zone		
DE-ISOLATE zone		
set zone -> TEST		
set zone -> TEST OFF		
activate ZONE TEST		
set zone -> RENOVATION		
ok:execute	F1:zones	C:end

ISOLATION	Zones: 1
01 detector zone ISOLATED	
main building/1st floor	
conference room	
F1:function	F2:menu

ZONE reactivation procedure

1. Select the *message category* by pressing the *Isolation* key

2. Select the zone to be de-isolated

→ The message is displayed in inverted colors

3. Press **ISOLATE**

→ The *ZONE* is reactivated, that is, the isolation is cancelled

ISOLATION	Zones: 1
01 detector zone ISOLATED	
main building/1st floor	
conference room	
F1:function	F2:menu

Isolation of individual detectors

When does a detector have to be isolated ?

Only when it is damaged or defective until it is replaced.

Note

An isolated detector **cannot generate any messages**.

The isolation of detectors only makes sense if the corresponding ZONE is de-isolated

Isolate a detector via the menu

Steps 1 to 4 are identical to «Zone isolation» as described above

5. Press **OK**
→ The *ELEMENTS* summary is displayed
Press **↓** to select the desired ELEMENT
6. Press **F1**
→ The *FUNCTION LIST 'element'* is displayed
Press **↓** to select the function «ISOLATE element» and press **OK**
→ The selected detector is isolated and displayed spontaneously if no messages of higher priority are pending.

Note

If **all** elements of a zone are isolated, the corresponding **zone** is automatically **isolated** as well.

ELEMENTS 'fire'	
01 conference room	
02 conference room	
03 conference room	
04 conference room	
F2:zone F1:function	

FUNCTION LIST 'element':		
poll INFORMATION 'element'		
ISOLATE element		
DE-ISOLATE element		
ACTIVATE element		
DEACTIVATE element		
ok:execute	F1:element	C:end

ISOLATION		Zones: 1
01 detector ISOLATED		
main building / 1st floor		
conference room		
F1:function F2:menu		

Reactivate a detector (element)

1. Select the *message category* by pressing the *Isolation* key. The message is displayed in inverted colors.
2. Press **F1**
→ The *FUNCTION LIST 'element'* is displayed
Press **↓** to select the function «DE-ISOLATE element» and press **OK**
→ The detector is reactivated

ISOLATION		Zones: 1
01 detector ISOLATED		
main building / 1st floor		
conference room		
F1:function F2:menu		

FUNCTION LIST 'element'		
poll INFORMATION 'element'		
ISOLATE element		
DE-ISOLATE element		
ACTIVATE element		
DEACTIVATE element		
ok:execute	F1:element	C:end

Isolate a detector when a fault message is pending

1. Select the message category by pressing the *Faults* key, then select the desired message by scrolling with **↓**, if necessary. The selected message is displayed in inverted colors.
2. Press **F1**
→ The *FUNCTION LIST 'element'* is displayed
Press **↓** to select the function «ISOLATE element» and press **OK** to confirm
→ The detector is reactivated

FAULTS	
01 detector	
main building / 1st floor	
room 102	
F1:function F2:menu	

FUNCTION LIST 'element'		
poll INFORMATION 'element'		
ISOLATE element		
DE-ISOLATE element		
ACTIVATE element		
DEACTIVATE element		
ok:execute	F1:element	C:end

What to do in case of reported fault messages?

1. Confirm the message by pressing **ACK**
2. Read the fault location on the display
3. Go to the fault location
4. If the fault cannot be removed call the *Cerberus service organization*

What remedies are available to the user?

Defective automatic detector

Go to the location of the defective detector,

if the detector is missing:

→ *reinsert the detector*

if the detector is defective:

→ *replace it with a spare detector*

Important: *only replace a defective detector with a unit of the same type.*

FAULTS	Zones: 1
01 detector main building / 1st floor room 102	
F1:function	F2:menu

Defective manual call point

Go the location of the defective call point,

if the glass pane is broken:

→ *replace the glass pane*

if there is any other defect:

→ *call the Cerberus service organization*

FAULTS	Zones: 1
01 call point GLASS BROKEN main building / 2nd floor CORRIDOR	
F1:function	F2:menu

Printer out of paper

Go to the printer,

→ *insert a new paper roll,
see section «Printer: Paper replenishing»
page 31*

FAULTS	Zones: 0
01 printer terminal PAPER END main building / 1st floor conference room	
F1:function	F2:menu

Mains supply failure

Mains failure in the public supply network:

→ *no action required*

the emergency power battery supplies the system for at least 24.5 hours (depending on the user's specification up to 72 hours)

Mains supply ok:

→ *check the power fuse (main distribution panel of the building) and replace the fuse, if it is blown.*

FAULTS	Zones: 0
01 mains failure control unit, basement	
F1:function	F2:menu

Note

Isolated detectors also cause a fault message.

For all other faults call the **Cerberus service organization**

Mode 'Detector test'

What is the «Detector test» mode for?

The mode «Detector test» allows individual on-site function testing of automatic fire detectors and manual call points without generating an alarm message.

Automatic fire detectors are actuated with a special detector tester.

Interactive detectors are set to the special parameter set 'Test' in order to achieve a fast activation with the detector tester.

Manual call points are activated depending on the type:

- From externally with a special test key without breaking the glass pane or opening the housing.
- Simply by opening the door of the manual call point.

Test alarm is the active state of automatic fire detectors or manual call points in «Detector test» mode. A test alarm **does not** generate a danger message in the control console. That means that neither acoustical alarm devices nor remote transmission or any other control functions are activated.

Test alarms are recorded in the event memory and logged spontaneously, if a printer is connected.

How to set detectors or manual call points to mode «Detector test»?

This is normally done on the **section** level, but also possible on the **zone** level.

It is **not** possible to set an individual fire detector or manual call point (element) to «Detector test».

Zones or **sections** set to «Detector test» are displayed spontaneously as a message in the category 'Isolation'

Set all detector zones within a SECTION to «Detector test»

1. Press **F2**
→ The **MAIN MENU** is displayed
Press **↓** to select the desired menu item.
2. Press **ok**
→ The **AREAS** overview is displayed
Press **↓** to select the desired AREA
3. Press **ok**
→ The **SECTIONS** overview is displayed
Press **↓** to select the desired SECTION
4. Press **F1**
→ The **FUNCTION LIST 'section'** is displayed
With **↓** select the function «set all DETECTOR zones → TEST» and press **ok** (automatic detectors only).

→ All zones of automatic detectors that belong to this section are set to «Detector test»
Indicator «Detector test mode» is on
Same procedure for manual call points

```
MAIN MENU
FIRE detection
EXTINGUISHING sections
CONTROL in- /outputs
GEOGRAPHICAL location
DEVICE level
logical address (CSX no.)
ok:select      F1:function      C:end
```

```
AREAS
01 main building
02 factory
ok:section      F2:menu      F1:function
```

```
SECTIONS
01 ground floor
02 1st floor
03 lift shaft
04 2nd floor
ok:zone      F2:area      F1:function
```

```
FUNCTION LIST 'section':
ISOLATE all DETECTOR zones
DE-ISOLATE all DETECTOR zones
ISOLATE all CALL POINT zones
DE-ISOLATE all CALL POINT zones
set all DETECTOR zones → TEST
terminate TEST of all DETECTOR zones
ok:execute      F1:sections      C:end
```

Recommendations for detector test

- Perform the function test periodically. The interval of this test is determined by the service engineer.
- Switch only the fire detectors of **one** SECTION at a time to «Detector test», never the entire building.
- For manual call points the function test needs to be performed only based on a spot-check.
- Test automatic fire detectors and manual call points of the same room always separately.
- Do not set them to «Detector test» simultaneously.
- After the test work has been completed **immediately cancel** the mode «Detector test».

Testing of automatic *AlgoRex*® detectors

1. Set the SECTION (or zone) to «Detector test» mode.
2. Place the detector tester on the detector.
Observe the marking!
→ For smoke detectors and multisensor smoke detectors the detector exchanger and tester DZ1193 is needed:
→ For heat detectors the detector tester RE6T is required:
The temperature rise is simulated with a hot-air blower
3. Wait until the response indicator on the detector flashes.
4. Remove the detector tester.
→ The function test is completed. Go to next detector


Neural smoke detector





Smoke detector



Detector exchanger and tester DZ1193



Heat detector



Detector tester RE6T


Note

Smoke detectors, multisensor smoke detectors and heat detectors have different housings (see illustration).

Testing of manual call points

Manual call points DM1101, DM1151 (type KAC)

1. Set the manual call point ZONE to «Detector test» mode.
2. Insert the test key into the opening
→ «Test alarm» is simulated.
3. Wait until the response indicator of the manual call point flashes.
4. Remove the test key.
→ The function test is completed



Terminate «Detector test» for all detector zones within a SECTION

1. Press **F2**

→ The MAIN MENU is displayed

MAIN MENU		
FIRE detection		
EXTINGUISHING sections		
CONTROL in- /outputs		
GEOGRAPHICAL location		
DEVICE level		
logical address (CSX no.)		
ok:select	F1:function	C:end

2. Press **ok**

→ The AREAS overview is displayed

Press **↓** to select the desired AREA

AREAS		
01 main building		
ok:section	F2:menu	F1:function

3. Press **ok**

→ The SECTIONS overview is displayed

Press **↓** to select the SECTION that is on 'detector test'

SECTIONS		
01 ground floor		
02 1st floor		
03 lift shaft		
04 2nd floor		
ok:zone	F2:area	F1:function

4. Press **F1**

→ The FUNCTION LIST 'section' is displayed

With **↓** select the function «terminate TEST of all DETECTOR zones» and press **ok**

FUNCTION LIST 'section' :		
DE-ISOLATE all DETECTOR zones		
ISOLATE all CALL POINT zones		
DE-ISOLATE all CALL POINT zones		
set all DETECTOR zones -> TEST		
terminate TEST of all DETECTOR zones		
set all CALL POINT zones -> TEST		
ok:execute	F1:sections	C:end

→ The «Detector test» is now cancelled for all detector zones of this section

Poll 'test alarms' in the event memory

1. Press **F2**
 → The MAIN MENU is displayed
 Press **↓** to select DEVICE level
2. Press **ok**
 → The STATIONS overview is displayed
 Press **↓** to select the desired STATION
3. Press **F1**
 → The function list Control unit is displayed
 Press **↓** to select 'poll EVENT MEMORY'
4. Press **ok**
 → The function list Event Memory is displayed
 Press **↓** to select 'poll all TEST ALARM' messages
5. Press **ok**
 → The TEST Alarms are displayed
 use **↑** and **↓** to poll the test alarms

```
MAIN MENU
FIRE detection
EXTINGUISHING sections
CONTROL in- /outputs
GEOGRAPHICAL location
DEVICE level
logical address (CSX no.)
ok:select      F1:function      C:end
```

```
STATIONS
01 CC1142 CBUS no1
02 CI1142 CBUS no2
05 CT1142 CBUS no5
ok:funct.unit  F2:menu      F1:function
```

```
FUNCTION LIST 'terminal':
poll INFORMATION 'terminal'
initiate LAMP TEST
set contrast of DISPLAY
set sound level of BUZZER
poll EVENT MEMORY 'terminal'
ISOLATE PRINTER 'terminal'
ok:execute      F2:stations      c:end
```

```
FUNCTION LIST 'event memory':
poll all messages
poll all DANGER messages
poll all FAULT messages
poll all DISCONNECTION messages
poll all INFORMATION messages
poll all TEST-ALARM messages
ok:execute      F1:station      F2:->date/time
```

```
EVENT MEMORY
**** TOP OF LIST ****
03-SEPT-1997 16:15:52  INFORMATION
+detector TEST ACTIVATION
  main building / 1st floor
  room 102
04-SEPT-1997 09:00:59  INFORMATION
^/v:scroll      F1:print      F2:->date/time
```

Mode 'Installation test'

What is the mode «Installation test» for?

The mode «Installation test» allows to test the correct function of the whole fire detection system including fire controls, acoustical alarm devices, etc. All functions remain enabled.

Make sure that the remote transmission is isolated or the fire department is informed about the test activities.

In the mode 'Installation test' **interactive detectors become more sensitive and respond faster** (response behavior as in mode «Detector test»).

The mode 'Installation test' shall be carried out only by security staff and serves basically to test the alarm organization and fire controls.

After the test work has been completed **immediately cancel** the mode «Installation test».

Mode «Installation test» is normally enabled and disabled on the level 'ZONE' but also possible on the level 'SECTION'

Setting a zone to mode «Installation test»

1. Press **F2**
→ The MAIN MENU is displayed
2. Press **ok**
→ The AREAS overview is displayed
Press **↓** to select the desired AREA
3. Press **ok**
→ The SECTIONS overview is displayed
Press **↓** to select the desired SECTION
4. Press **ok**
→ The ZONES overview is displayed
Press **↓** to select the desired ZONE
5. Press **F1**
→ The FUNCTION LIST 'zone' is displayed
With **↓** scroll to the function
«set zone -> INSTALLATION TEST» and press **ok**
→ The ZONE is set to mode «Installation test»

```
MAIN MENU
FIRE detection
EXTINGUISHING sections
CONTROL in- /outputs
GEOGRAPHICAL location
DEVICE level
logical address (CSX no.)
ok:select      F1:function      C:end
```

```
AREAS
01 main building
ok:section     F2:menu      F1:function
```

```
SECTIONS 'fire'
01 ground floor
02 1st floor
03 lift shaft
04 2nd floor
ok:zone        F2:area      F1:function
```

```
ZONES 'fire'
01 room 101
02 1st floor
03 storage room
04 conference room
05 corridor
ok:element     F2:section   F1:function
```

```
FUNCTION LIST 'zone' :
set zone -> TEST OFF
activate FAULT TEST
set zone -> RENOVATION
set zone -> RENOVATION OFF
set zone -> INSTALLATION TEST
set zone -> INSTALLATION TEST OFF
ok:execute     F1:zones     C:end
```

Termination of mode «Installation test» of a zone

1. Press the **Information** key and select the desired message by pressing **↓**, if necessary. The selected message is displayed in inverted colors.
2. Press **F1**
→ The FUNCTION LIST 'zone' is displayed
With **↓** scroll to the function
«set zone -> INSTALLATION TEST OFF» and press **ok**
→ The ZONE is set to normal operation mode

```
INFORMATION                                Total: 1
01 detector zone INSTALL. TEST
main building / 1st floor
conference room
F1:function      F2:menu
```

```
FUNCTION LIST 'zone':
set zone -> TEST OFF
activate FAULT TEST
set zone -> RENOVATION
set zone -> RENOVATION OFF
set zone -> INSTALLATION TEST
set zone -> INSTALLATION TEST OFF
ok:execute     F1:zones     C:end
```

Mode 'Renovation'

What is the «Renovation» mode for?

In «Renovation» mode, *automatic detectors are much less sensitive*. This may be required while unusual work is in progress (e.g. during renovation of a building).

The fire detection system remains working, the remote transmission of alarm and fault messages is enabled. Manual call points work as in normal operation mode.

Detectors in the mode 'Renovation' are from the insurance and approval point of view **out of order**. This is why the 'isolation' message is generated. Mode 'Renovation' is enabled and disabled on the level 'ZONE' only.

Mode 'Renovation' is enabled and disabled on the level 'ZONE' only.

Setting a zone to mode «Renovation»

1. Press **F2**
→ The MAIN MENU is displayed
2. Press **ok**
→ The AREAS overview is displayed
Press **↓** to select the desired AREA
3. Press **ok**
→ The SECTIONS overview is displayed
Press **↓** to select the desired SECTION
4. Press **ok**
→ The ZONES overview is displayed
Press **↓** to select the desired ZONE
5. Press **F1**
→ The FUNCTION LIST 'zone' is displayed
With **↓** scroll to the function
«set zone -> RENOVATION» and press **ok**
→ The ZONE is set to mode «Renovation»

```
MAIN MENU
FIRE detection
EXTINGUISHING sections
CONTROL in- /outputs
GEOGRAPHICAL location
DEVICE level
logical address (CSX no.)
ok:select      F1:function      C:end
```

```
AREAS
01 main building
ok:section      F2:menu      F1:function
```

```
SECTIONS 'fire'
01 ground floor
02 1st floor
03 lift shaft
04 2nd floor
ok:zone          F2:area      F1:function
```

```
ZONES 'fire'
01 room 101
02 1st floor
03 storage room
04 conference room
05 corridor
ok:element       F2:section   F1:function
```

```
FUNCTION LIST 'zone':
DE-ISOLATE zone
set zone -> TEST
set zone -> TEST OFF
activate FAULT TEST
set zone -> RENOVATION
set zone -> RENOVATION OFF
ok:execute       F1:zones     C:end
```

Termination of mode «Renovation» of a zone

1. Press the *Isolation* key and select the desired message by pressing **↓**, if necessary. The selected message is displayed in inverted colors.
2. Press **F1**
→ The FUNCTION LIST 'zone' is displayed
With **↓** scroll to the function
«set zone -> RENOVATION OFF» and press **ok**
→ The ZONE is set to normal operation mode

```
ISOLATION                      Zones: 1
01 detector zone RENOVATION
   main building / 1st floor
   conference room
F1:function                      F2:menu
```

```
FUNCTION LIST 'zone':
set zone -> TEST
set zone -> TEST OFF
activate FAULT TEST
set zone -> RENOVATION
set zone -> RENOVATION OFF
set zone -> INSTALLATION TEST
ok:execute       F1:zones     C:end
```

Remote transmission ISOLATE/DE-ISOLATE

This system is equipped with a remote transmission facility


for FIRE ALARM ☐ Yes, destination:
 ☐ No
 for FAULT ☐ Yes, destination:
 ☐ No

What is «Remote transmission»?

Remote transmission establishes a transmission path to the fire department in the event of a FIRE ALARM. For FAULT there is normally a separate path established.

When does the remote transmission have to be isolated?

Normally the remote transmission operates in active stand-by. Isolation is needed only in special cases, for example for testing the control functions. For this test the *Remote alarm isolate* key ❶ on the control console has to be pressed. The «ISOLATED» state is signalled by the indicator ❷.



ISOLATING the remote transmission

Press key ❶

- The corresponding isolation message is displayed
- Indicator ❷ turns on
- The FIRE ALARM remote transmission is isolated

ISOLATION		Zones: 0
01	RT 'fire' ISOLATED	
	main building	
	remote transmission channel FIRE	
02	RT 'fire' ISOLATED	
	factory	
	remote transmission channel FIRE	
F1: function		F2: menu

DE-ISOLATING the remote transmission

Press key ❶ (toggling key)

- Indicator ❷ turns off
- The FIRE ALARM remote transmission is de-isolated and switched to stand-by

Note


The remote transmission can also be isolated and de-isolated via the menu, separately for «Alarm» and «Fault».

The remote transmission must be periodically checked by activating a manual call point. The fire department must be notified before the test is initiated.

Alarm devices ISOLATE/DE-ISOLATE

When do alarm devices (horns, sirens, etc.) have to be isolated ?

Normally the alarm devices operate in active stand-by. Isolation is needed only in special cases, for example for testing the control functions.



ISOLATING the alarm devices

Press key ❶

- The corresponding isolation message is displayed
- Indicator ❷ turns on
- The alarm devices (warning system AND external bell) are isolated

ISOLATION		Zones: 0
01	external bell ISOLATED	
	main building	
	external horn (horn II)	
02	warning system ISOLATED	
	main building	
	internal horn (horn I)	
F1: function		F2: menu

DE-ISOLATING the alarm devices

Press key ❶ (toggling key)

- Indicator ❷ turns on
- The alarm devices are de-isolated and switched to stand-by

Note

The alarm devices can also be isolated and de-isolated via the menu.

Printer ISOLATE/DE-ISOLATE

This system is equipped with a printer ☐ Yes
☐ No

When does the printer have to be ISOLATED?

Normally the printer (if installed) operates in active stand-by. Isolation is needed only in special cases (for example to change the paper). The printer can be isolated and de-isolated via the menu. The «ISOLATED» state is shown on the display.

ISOLATING the printer

1. Press **F2**
→ The **MAIN MENU** is displayed
With **↓** choose the function «DEVICE level»
2. Press **ok**
→ The **STATIONS** overview is displayed
Press **↓**, if necessary, to select the desired station (control unit or terminal)
3. Press **F1**
→ The **FUNCTION LIST 'control unit'** is displayed
Press **↓** to select «ISOLATE printer» and press **ok**
→ The printer is isolated

```
MAIN MENU
FIRE detection
EXTINGUISHING sections
CONTROL in- /outputs
GEOGRAPHICAL location
DEVICE level
logical address (CSX no.)
ok:select      F1:function      C:end
```

```
STATIONS
01 control unit CC1140 ground floor
02 terminal CT11 corridor 1st floor

ok:funct.unit  F2:menu      F1:function
```

```
FUNCTION LIST 'terminal':
initiate LAMP TEST
set contrast of DISPLAY
set sound level of BUZZER
poll EVENT MEMORY 'terminal'
ISOLATE printer 'terminal'
DE-ISOLATE printer 'terminal'
ok:execute     F1:stations   C:end
```

DE-ISOLATING the printer

1. Press the *Isolation* key and select the desired message by pressing **↓**, if necessary. The selected message is displayed in inverted colors.
2. Press **F1**
→ The **FUNCTION LIST 'control unit'** is displayed
With **↓** select the function «DE-ISOLATE printer» and press **ok**
→ The printer is de-isolated


```
ISOLATION                      Zones: 0
01 printer 'terminal' ISOLATED
   reception ground floor

F1:function                      F2:menu
```

```
FUNCTION LIST 'terminal':
set contrast of DISPLAY
set sound level of BUZZER
poll EVENT MEMORY 'terminal'
ISOLATE printer 'terminal'
DE-ISOLATE printer 'terminal'
initiate PRINTER TEST 'terminal'
ok:execute     F1:stations   C:end
```

Printer B2Q191: paper replenishing

Valid for this system ☐ Yes, system equipped with printer B2Q191
☐ No printer of this type installed



Print intensity

If the print intensity is too low, call the Cerberus service organization.

Spare paper rolls

Cerberus part no. 379 977 (= 4 pcs.)
 or – JUJU TP 50KS-A
 – HONSHU PS 65 B1
 – MITSUBISHI F-200 U7X

Lamp test

What is the «Lamp test» used for?

For testing the correct functioning of all indicators (LEDs), the display, and the alarm buzzer.
All visual and audible devices of the control console are activated for a few seconds.

Initiate lamp test

1. Press **F2**
→ The **MAIN MENU** is displayed
With **↓** choose the function «**DEVICE level**»
2. Press **ok**
→ The **STATIONS** overview is displayed
Press **↓** to select the desired station (terminal)
3. Press **F1**
→ The **FUNCTION LIST 'terminal'** is displayed
Press **↓** to select «**initiate LAMP TEST**» and press **ok**
→ The lamp test is initiated

```
MAIN MENU
FIRE detection
EXTINGUISHING sections
CONTROL in- /outputs
GEOGRAPHICAL location
DEVICE level
logical address (CSX no.)
ok:select      F1:function      C:end
```

```
STATIONS
01 control unit CC1140 ground floor
02 terminal CT11 corridor 1st floor
ok:funct.unit  F2:menu          F1:function
```

```
FUNCTION LIST 'terminal':
poll INFORMATION 'terminal'
initiate LAMP TEST
set contrast of DISPLAY
set sound level of BUZZER
poll EVENT MEMORY (terminal)
ISOLATE PRINTER (terminal)
ok:execute     F1:stations      C:end
```


Alarm counter

What is the purpose of polling the alarm counter?

The alarm counter shows the number of past alarm events.

Polling alarm counter

1. Press **F2**
→ The MAIN MENU is displayed
2. Press **OK**
→ The AREAS overview is displayed
Press **↓** to select the desired AREA
3. Press **F1**
→ The FUNCTION LIST 'area' is displayed
Press **↓** to select «poll COUNTER 'fire alarms'» or
«poll COUNTER 'remote alarms'» and press **OK**

→ The number of alarms is displayed

```
MAIN MENU
FIRE detection
EXTINGUISHING sections
CONTROL in- /outputs
GEOGRAPHICAL location
DEVICE level
logical address (CSX no.)
ok:select      F1:function      C:end
```

```
AREAS
01 main building
ok:section      F2:menu      F1:function
```

```
FUNCTION LIST 'area':
switching MANNED/UNMANNED
poll COUNTER 'fire alarms'
poll COUNTER 'remote alarms'
DE-ISOLATE alarm HORNS
ISOLATE alarm HORNS
alarm HORNS -> START
ok:execute      F1:areas      C:end
```

```
COUNTER 'fire alarms' : 4
```

Event memory

Polling event memory of an 'AREA'

1. Press **F2**
→ The MAIN MENU is displayed
2. Press **OK**
→ The AREAS overview is displayed
Press **↓** to select the desired AREA
3. Press **F1**
→ The FUNCTION LIST 'area' is displayed
Press **↓** to select «poll EVENT MEMORY»
4. Press **OK**
→ The FUNCTION LIST 'event memory' is displayed
Press **↓**, if necessary, to select the desired function and press **OK**

→ The display now shows the desired list.
Either the latest entry is visible completely, older entries (if existing) can be scrolled by pressing **↑**

Note

with **F2**:->date/time a entry of a particular date/time can be selected and displayed.

MAIN MENU		
FIRE detection		
EXTINGUISHING sections		
CONTROL in- /outputs		
GEOGRAPHICAL location		
DEVICE level		
logical address (CSX no.)		
ok:select	F1:function	C:end

AREAS		
01 main building		
02 machine building		
03 warehouse building		
ok:section	F2:menu	F1:function

FUNCTION LIST 'area':		
ISOLATE REMOTE transm. 'fire'		
DE-ISOLATE REMOTE transm. 'others'		
ISOLATE REMOTE transm. 'others'		
DE-ISOLATE REMOTE transm. 'fault'		
ISOLATE REMOTE transm. 'fault'		
poll EVENT MEMORY		
ok:execute	F1:areas	C:end

FUNCTION LIST 'event memory':		
poll all messages		
poll all DANGER messages		
poll all FAULT messages		
poll all DISCONNECTION messages		
poll all INFORMATION messages		
poll all TEST-ALARM messages		
ok:execute	F1:areas	F2:->date/time

EVENT MEMORY		
machine building		
engine room		
21-FEB-1996 11:26:43 INFORMATION		
-detector zone INSTALL. TEST		
machine building		
compressor room		
^/v:scroll	F1:print	F2:->date/time

Printing selected entries of the event memory

Steps 1..4 are identical to «Polling event memory of an area» as described above

5. Press **F1**
→ The 'printout EVENT MEMORY' menu is displayed
Press **F2** to print all entries **or** select desired range of date and time to print out particular events.

Use **↑** and **↓** to set date and time and press **F1** to select the next field.
Press **OK** to print out selected entries.

→ During the print out procedure on the bottom line a flashing "printing" in inverted colors is displayed.

printout EVENT MEMORY		
VV		
Printout starts at: 08:00 21-FEB-1996		
Printout stops at: 08:00 21-FEB-1996		
ok:set	F1:next field	F2:print all

printout EVENT MEMORY		
...		
... printing ...		

Note

The event memory can only be printed out, if the printer is connected to the operated terminal.

Set clock and date

Normally the date and time do not have to be corrected!

The date and time are set by the service engineer when installing the system.

→ The summer/winter time changeover is performed automatically.

→ Time and date are always displayed when the password is entered.

Setting the clock

1. Press **F2**
→ The MAIN MENU is displayed
2. Press **F1**
→ The FUNCTION LIST 'installation' is displayed
3. Press **ok**
→ An input prompt is displayed
Enter the current time and press **ok**
(2 digits each for hours / minutes / seconds)
→ The new time is read in and loaded

MAIN MENU		
FIRE detection		
EXTINGUISHING sections		
CONTROL in- /outputs		
GEOGRAPHICAL location		
DEVICE level		
logical address (CSX no.)		
ok:select	F1:function	C:end

FUNCTION LIST 'installation':		
set CLOCK		
set DATE		
re-configuration C-bus		
ok:execute	F1:menu	C:end

SET CLOCK		
HHMMSS		
0..9,del:edit		
ok:set	C:cancel	

Setting the date

1. Press **F2**
→ The MAIN MENU is displayed
2. Press **F1**
→ The FUNCTION LIST 'installation' is displayed
Press **↓** to select the function «set DATE»
3. Press **ok**
→ An input prompt is displayed
Enter the current date and press **ok**
(2 digits each for day / month / year)
→ The new date is read in and loaded

MAIN MENU		
FIRE detection		
EXTINGUISHING sections		
CONTROL in- /outputs		
GEOGRAPHICAL location		
DEVICE level		
logical address (CSX no.)		
ok:select	F1:function	C:end

FUNCTION LIST 'installation':		
set CLOCK		
set DATE		
re-configuration C-bus		
ok:execute	F1:menu	C:end

SET DATE		
DDMMYY		
0..9,del:edit		
ok:set	C:cancel	

Overview operating menus

To enter 'MAIN MENU' press **F2**

```

MAIN MENU
FIRE detection
EXTINGUISHING sections
CONTROL in- /outputs
GEOGRAPHICAL location
DEVICE level
logical address (CSX no.)
ok:select      F1:function      C:end
  
```

Note

F1 = press **F1**

ok = press **ok**

F1 **FUNCTION LIST 'installation'**

- set CLOCK
- set DATE
- re-configuration C-bus
- acknowledge all
- reset all

select FIRE section

ok

AREAS...

ok

F1 **FUNCTION LIST 'area'**

- switching MANNED/UNMANNED
- poll COUNTER 'fire alarms'
- reset COUNTER 'fire alarms'-----
- poll COUNTER 'remote alarms'
- DE-ISOLATE alarm HORNS
- ISOLATE alarm HORNS
- alarm HORN -> START
- alarm HORN -> STOP
- initiate TEST alarm HORN
- DE-ISOLATE REMOTE transm. 'fire'
- ISOLATE REMOTE transm. 'fire'
- DE-ISOLATE REMOTE transm. 'others'
- ISOLATE REMOTE transm. 'others'
- DE-ISOLATE REMOTE transm. 'fault'
- ISOLATE REMOTE transm. 'fault'
- poll EVENT MEMORY-----ok

FUNCTION LIST 'event memory'

- poll all messages
- poll all DANGER messages
- poll all FAULT messages
- poll all DISCONNECTION messages
- poll all INFORMATION messages
- poll all TEST-ALARM messages

access level 3 'service'

SECTIONS...

ok

F1 **FUNCTION LIST 'section'**

- ISOLATE all DETECTOR zones
- DE-ISOLATE all DETECTOR zones
- ISOLATE all CALL POINT zones
- DE-ISOLATE all CALL POINT zones
- set all DETECTOR zones -> TEST
- terminate TEST of all DETECTOR zones
- set all CALL POINT zones -> TEST
- terminate TEST of all CALL POINT zones
- set all DETECTOR ZONES -> INSTALL. TEST
- terminate INSTALL.TEST of all DET.zones

ZONES...

ok

F1 **FUNCTION LIST 'zone'**

- ISOLATE zone
- DE-ISOLATE zone
- set zone -> TEST
- set zone -> TEST OFF
- activate FAULT TEST
- set zone -> RENOVATION
- set zone -> RENOVATION OFF
- ACTIVATE zone-----
- set zone -> INSTALLATION TEST
- set zone -> INSTALLATION TEST OFF

access level 3 'service'

ELEMENTS...

F1 **FUNCTION LIST 'element'**

- poll INFORMATION 'element'
- ISOLATE element
- DE-ISOLATE element
- ACTIVATE element
- DEACTIVATE element
- CHANGE parameter set-----
- parameter set -> DEFAULT-----

see document e1957

To enter 'MAIN MENU' press **F2**

```

MAIN MENU
FIRE section
EXTINGUISHING sections
CONTROL in- /outputs
GEOGRAPHICAL location
DEVICE level
logical address (CSX no.)
ok:select      F1:function      C:end
    
```

Note

F1 = press **F1**

ok = press **ok**

FUNCTION LIST 'installation'

- set CLOCK
- set DATE
- re-configuration C-bus
- acknowledge all
- reset all

EXTINGUISHING sections (details see document e1956)

ok

AREAS... **F1**

ok

FUNCTION LIST 'area'

- switching MANNED/UNMANNED
- poll COUNTER 'fire alarms'
- reset COUNTER 'fire alarms' -----
- poll COUNTER 'remote alarms'
- DE-ISOLATE alarm HORN
- ISOLATE alarm HORN
- alarm HORN -> START
- alarm HORN -> STOP
- initiate TEST alarm HORN
- DE-ISOLATE REMOTE transm. 'fire'
- ISOLATE REMOTE transm. 'fire'
- DE-ISOLATE REMOTE transm. 'others'
- ISOLATE REMOTE transm. 'others'
- DE-ISOLATE REMOTE transm. 'fault'
- ISOLATE REMOTE transm. 'fault'
- poll EVENT MEMORY ----- ok

FUNCTION LIST 'event memory'

- poll all messages
- poll all DANGER messages
- poll all FAULT messages
- poll all DISCONNECTION messages
- poll all INFORMATION messages
- poll all TEST-ALARM messages

access level 3 'service'

SECTIONS... **F1**

ok

FUNCTION LIST 'section'

- BLOCKING autom.extinguishing -----
- ENABLING autom.extinguishing -----
- BLOCKING autom.& man. extinguishing release -----
- ENABLING autom.& man. extinguishing release -----
- ISOLATE all DETECTOR zones -----
- DE-ISOLATE all DETECTOR zones -----
- set all DETECTOR zones -> TEST -----
- terminate TEST of all DETECTOR zones -----
- set all DETECTOR zones ->INSTALL: TEST -----
- terminate INSTALL.TEST of all DET. zones -----
- set extinguishing control -> REVISION -----
- terminate REVISION -----
- set extinguishing control -> TEST -----
- terminate TEST of exting. control -----
- initiate TEST "horn" -----
- initiate TEST "warning panel" -----

see document e1956

access level 3 'service'

ZONES... **F1**

ok

FUNCTION LIST 'zone'

- ISOLATE zone
- DE-ISOLATE zone
- set zone -> TEST
- set zone -> TEST OFF
- activate FAULT TEST
- set zone -> RENOVATION
- set zone -> RENOVATION OFF
- ACTIVATE zone -----
- set zone -> INSTALLATION TEST
- set zone -> INSTALLATION TEST OFF

access level 3 'service'

ELEMENTS... **F1**

FUNCTION LIST 'element'

- poll INFORMATION 'element'
- ISOLATE element
- DE-ISOLATE element
- ACTIVATE element
- DEACTIVATE element
- CHANGE parameter set -----
- parameter set -> DEFAULT -----

see document e1957

To enter 'MAIN MENU' press **F2**

```

MAIN MENU
FIRE detection
EXTINGUISHING sections
CONTROL in- /outputs
GEOGRAPHICAL location
DEVICE level
logical address (CSX no.)
ok:select      F1:function      C:end
    
```

Note

F1 = press **F1**

ok = press **ok**

F1 **FUNCTION LIST 'installation'**
 set CLOCK
 set DATE
 re-configuration C-bus
 acknowledge all
 reset all

control in-/outputs

ok

AREAS...

ok

F1 **FUNCTION LIST 'area'**
 switching MANNED/UNMANNED
 poll COUNTER 'fire alarms'
 reset COUNTER 'fire alarms' -----
 poll COUNTER 'remote alarms'
 DE-ISOLATE alarm HORN
 ISOLATE alarm HORN
 alarm HORN -> START
 alarm HORN -> STOP
 initiate TEST alarm HORN
 DE-ISOLATE REMOTE transm. 'fire'
 ISOLATE REMOTE transm. 'fire'
 DE-ISOLATE REMOTE transm. 'others'
 ISOLATE REMOTE transm. 'others'
 DE-ISOLATE REMOTE transm. 'fault'
 ISOLATE REMOTE transm. 'fault'
 poll EVENT MEMORY ----- ok

FUNCTION LIST 'event memory'
 poll all messages
 poll all DANGER messages
 poll all FAULT messages
 poll all DISCONNECTION messages
 poll all INFORMATION messages
 poll all TEST-ALARM messages

access level 3 'service'

SECTIONS...

ok

F1 **FUNCTION LIST 'section'**
 ISOLATE all ZONES
 DE-ISOLATE all ZONES

ZONES...

ok

Note:

for time channels no function available


F1 **FUNCTION LIST 'zone'**
 ISOLATE zone
 DE-ISOLATE zone
 ACTIVATE zone -----
 DEACTIVATE zone -----

access level 3 'service'

ELEMENTS...

F1 **FUNCTION LIST 'element'**
 poll INFORMATION 'element'
 DISCONNECT element
 CONNECT element
 ACTIVATE element
 DEACTIVATE element

To enter 'MAIN MENU' press **F2**



To enter 'MAIN MENU' press **F2**


```

MAIN MENU
FIRE detection
EXTINGUISHING sections
CONTROL in- /outputs
GEOGRAPHICAL location
DEVICE level
logical address (CSX no.)
ok:select      F1:function      C:end
    
```


Note

F1 = press **F1**

ok = press **ok**



To enter 'MAIN MENU' press 



Siemens Building Technologies AG
Cerberus Division
CH-8708 Männedorf
Alte Landstrasse 411
Tel. +41 1 - 922 61 11
Fax +41 1 - 922 64 50
www.cerberus.ch

